

Unicount Round Counter

for Dillon XL650 / XL750 or Dillon Super 1050 / RL1100

Instructions for use



Armanov d.o.o. Dobrave 3, 1236 Trzin, Slovenija Tel: +386 30 467 000 www.armanov.com


The Armanov Digital
Round Counter tracks the
quantity of reloaded
ammunition across one
or more calibers. It
enables you to monitor
your reloading pace and
manually adjust the
count if you skip a
position or experience a
dry feed. Additionally, it
features an integrated
lighting switch and a low
powder sensor.

- Install the counter and connect all sensors. Then, power on the device.
- 2 Select your desired caliber (including custom calibers 1–5), and if needed set a batch size from the main menu tabs.
- 3 Monitor your production numbers and reloading pace in real-time as you reload ammunition.
- 4 Review detailed statistics on produced rounds, including quantities per caliber and total counts.
- Set predefined batch sizes to efficiently use up your remaining supplies, such as leftover bullets, primers, and cases.
- 6 Activate the integrated powder sensor to ensure you never run out of powder during reloading.


Mounting


XL650/750 Super 1050/RL1100

Display




Counter sensor







Powder sensor





LED Light





Controls & Connections






Home screen layout & settings

Counter memory

After counter powers on you can toggle between 3 home screen styles by pressing the VIEW button.







COUNT ADJUSTMENT

You can manually adjust count for any reason by pressing UP/DOWN buttons.







COUNT RESET

If you want to start fresh, you can reset the current count of the selected caliber by pressing the RESET button; this does not affect the total combined count for this caliber shown in the Rounds tab.





Counter memory

To extend memory lifespan (EEPROM), the counter does not write to memory after every round. Instead, it saves the count 30 sec after the last detected change. Consequently, if the device is powered off immediately, the most recent few rounds may not be recorded. Wait at least 30 sec before powering off the device to ensure the data is accurately saved.

LED on/off switch & Count Confirmation

Use the dedicated LED button to operate the supplied LED light. You can also connect to the built-in LED on Armanov Dillon RL 1050/1100 toolhead. Cable sold seperatley. The LED will automatically shut off after 15min of inactivity. Just press LED button to turn in on again.

COUNT CONFIRMATION

With a long press (3s) of the LED button you can toggle between BEEP, LED flash or NO count confirmation. This setting is








stored by the counter, and doesn't affect the LED ON/OFF setting.

Main menu & settings




Main menu


By pressing the MENU button you can toggle between home screen and main menu. Within the main menu, navigate through the available tabs (Counters, Batch Size, Notify, etc.) by pressing TAB button. To exit the main menu and return to the home screen, press the MENU button.

1 Rounds

Use the UP/DOWN buttons to scroll through calibers. When desired caliber is highlited, press TAB to navigate to next setting or press the MENU button to exit back to home screen. Here you can also reset the combined count of selected caliber to 0, by pressing RESET button.







CALIBER COUNT RESET

Here you can also reset the combined count of selected caliber to 0, by pressing RESET button; Total Rounds tab can be reset only by performing a factroy settings reset.

TOTAL ROUNDS COUNTER

The Total Rounds count displays the cumulative number of rounds processed across all calibers. Great for monitoring press overall cycles and performing maintanance and lubrication on regular basis. This count can only be reset by performing a factory reset.


2 Batch Size

Use the UP/DOWN buttons to select the desired batch size. Great if you need an exact number of rounds for example to fill a 100rd ammo box. When desired batch size is highlited, press TAB to proceed to next setting or press MENU to exit to the home screen.

Rounds Batch Size 200 Rounds Notify Powder Sensor Tab 150 Rounds 200 Rounds 300 Rounds Up / Down

TAB

press TAB





Batch Size	Powder Sensor OFF
	Powder Sensor ON
Notify	
Powder Sensor	
Tab	Up / Down

3 Notify

Set a notification to alert you before the batch is complete. Use the UP/DOWN buttons to choose how many rounds remain before the end of the batch when the notification will trigger. Usefull to help you leave an empty and clean shellplate for nex time. Press TAB to proceed to next setting or press MENU to exit to the home screen.

4 Powder Sensor

Toggle the powder sensor ON or OFF using the UP/DOWN buttons. When on, you will get a notification that reminds you to top upyour powder. Press TAB to jump back to Rounds settings or press MENU to exit to the home screen.

Factory reset

To perform a factory reset, first unplug the USB-C power supply. Then, press and hold the RESET button while plugging the USB-C power supply back in. Continue holding the RESET button until the counter has fully rebooted, then release the button. This process will reset all values and settings to their factory defaults.